

1. Open and lower the glove box by releasing the catch tabs on either side.
2. Insert key and turn to the on position (do not start the engine.)
3. Locate the programming connector behind the glove box. Connector must be jumped take either a jumper wire or bent paperclip and jump the connector. Connect one end of the wire or clip to the inside of the connector and the other end to a metal surface of the vehicle. Locks will cycle from lock to unlock.
4. Press any button on the remote being programmed, the locks will cycle again confirming successful programming. Repeat this step for any additional remotes
5. Remove jumper wire or clip to exit programming mode.