



1. Collect all remotes that you wish to program. This procedure will erase all previously programmed remotes. You must program all existing and new remotes that you wish to use on the vehicle at this time.
2. Locate the Data Link Port underneath the driver side dashboard use image above for reference.
3. Close all doors, Insert key into ignition leave it in the Off position.
4. Jump terminal 1 and 4 off the Data Link Port, connect either a jumper wire or paperclip to terminal 1 and 4. Make contact to the metal surface inside the terminal. Leave two terminals connected.
5. Turn ignition to ACC than back to Off. Locks will cycle from lock to unlock signaling entering of programming mode. Must be performed within ten seconds of installing jumper wire.
6. Press lock or unlock three times on the remote being programmed. Locks will cycle signaling successful programming . Repeat this step for additional remotes.
- 7 . Remove jumper wire or clip to exit programming.