

1. Collect all remotes that you wish to program. This procedure will erase all previously programmed remotes. You must program all existing and new remotes that you wish to use on the vehicle at this time.
2. Locate programming connector on the driver side of the trunk. Remove any trim or carpeting to access the connector. Connector will be close to the tail light Connector is a port connected to a black and white wire. Connector will not be connected to anything
3. Next you must jump the programming connector. You may use a jumper wire or paper clip. Make contact to the metal connectors inside the ports with the paper clip or wire. locks will cycle from lock to unlock signaling entering of programming mode.
5. Press and hold lock and until locks cycle, this may take up to 15 seconds. This remote has been successfully programmed. Repeat this step for any additional remotes.
6. Remove jumper wire or paper clip to exit programming mode.