

1. Open Trunk place all remotes in vehicle.
2. Insert key in trunk lock and unlock five times. " Ready Fob Fob" will be displayed on the Driver Information Center.
3. Locate the remote pocket in the glove box or center console place the unprogrammed remote in the pocket. Have the buttons face the right (passenger) side of vehicle.
4. Vehicle will chime when the programming is complete. Place additional remotes to be programmed in the pocket now.
5. Remove remotes and test to exit programming.