- 1. Collect all remotes that you wish to program. This procedure will erase all previously programmed remotes. You must program all <u>existing and new remotes</u> that you wish to use on the vehicle at this time.
- 2. Close all doors, insert key into ignition do not turn it.
- 3. Hold the Unlock button on the driver's door DO NOT RELEASE.
- 4. Remove key from ignition, insert and remove key from ignition, insert key again and DO NOT remove it.
- 5. Release Unlock button on driver's door. Car will chime three times to signal entering of programming mode.
- 6. Press and hold the Lock and Unlock button on the remote being programmed until car chimes twice. This sound signals successful programming. Repeat this step for any additional remotes.
- 7. Remove key from ignition to end programming mode.