

1. Open the hood and find the Data Link Connector. Jump pin 12 to 8. You can use a jumper wire or a bent paper clip. Bend the wire or paperclip and make contact to pins 12 to 8.
2. Insert key and turn ignition to the On position. Press the Lock button on the remote two times. Vehicle will make a chime when programmed successfully
3. Exit programming turn off key and remove jumper wire.