

1. Locate programming connector it will be a green wire with a red connector on the end. The programming connector will be located on the passenger side trim cowls towards the top.
2. Use a jumper wire or paperclip to jump the programming connector. Connect one end of the wire or clip to the metal inside the connector and the other end to a metal surface of the car.
3. Insert key to the ignition and turn it to the On position (this will not start the car). Press any button on the remote being programmed locks will cycle to confirm programming. Repeat for any additional remotes.
4. Remove clip or wire to end programming.