

1. You will need to access the keyless entry module. To do this you need to remove the panel covering it which is right below the steering wheel.
2. Turn ignition to ON (position just before starting the car - do not start the car)
3. Now locate the keyless entry module and press the green button on the module - use a paper clip to do this.
4. Press and hold the green button the module until you see a light flash in the dash. Release when you see the light flash.
5. You now have 5 seconds to press the LOCK button on the remote. The buttons starting at the bottom are panic(red), unlock then lock which is the top button. Once you press the lock button the siren should chirp and/or the lights will flash to indicate successful programming of the remote.
6. If you have additional remotes to program repeat step 5 if you do not proceed to step 7.
7. Turn the ignition to OFF.