

1. Open the driver's side and insert key into the ignition.
2. As quickly as possible turn the ignition from ACC to LOCK THREE times you have 10 seconds to do this.
3. Close and open the driver's side door twice.
4. Turn the key to the ACC position and LOCK position FIVE times.
5. Close and open the driver's side door once. The door locks will cycle confirm that the vehicle is in programming mode.
6. Press the lock button once(top button) the door locks will cycle.
7. Press the unlock button once(middle button) the door locks will cycle.
8. If you have any other remotes to program repeat steps 6 and 7 for each additional. Otherwise proceed to step 9.
9. Remove key from ignition, programming is complete.