

1. Close all doors and fasten seat belt , Keep foot off brake pedal.
2. Turn ignition from Off to Run 4 times ending in Run ( Do not start the car, run position is just before the vehicle will start Off is turned all the way back when the key can be removed from the ignition ).  
Must be performed within 3 seconds
3. Turn ignition to Off , warning lights and clock will flash to signal programming mode
4. Press and Hold any button on the remote being programmed wait for lights to flash Could take up to 20 seconds. You have successfully programmed the remote. Repeat for additional remotes
3. Exit programming mode by turning on ignition.

.