

1. Insert Key and turn it to the RUN or ACC position (do not start the car.)
2. Locate the programming connector behind the passenger glove box. Two wires will be leading to the connector. The connector will not be connected to anything. Jump the terminals inside the connector. Use either a jumper wire or bent paperclip. Make contact to the metal inside each terminal. locks will cycle or horn will chirp signaling programming mode.
3. Press any button on the remote being programmed locks will cycle or horn will chirp signaling successful programming. Repeat for additional remotes.
4. Turn off ignition remove jumper wire.