

1. Turn ignition from Off to Run 5 times ending in Run (Do not start the car, run position is before the vehicle will start)ending in Run. Must be performing within 10 seconds. Locks will cycle signaling entering into programming mode. Keep foot off brake pedal.
2. Press any button on the remote being programmed, locks cycle confirming programming. Repeat this step for any addition remotes.
3. Turn key to off, locks will cycle to end programming mode.

.