



1. Collect all remotes that you wish to program. This procedure will erase all previously programmed remotes. You must program all existing and new remotes that you wish to use on the vehicle at this time.
2. Obtain a fused jumper wire and access the Data Link Connector. Located underneath driver side dashboard. See above picture for reference.
3. Connect terminal G with terminal A using a grounded jumper wire. Locks will cycle lock and unlock. Your vehicle has entered into programming mode.
4. Press any button on remote three times locks will cycle again confirming remote programming. Repeat this step for any additional remotes.
5. Remove the fused jumper wire.