- 1. Collect all remotes that you wish to program. This procedure will erase all previously programmed remotes. You must program all <u>existing and new remotes</u> that you wish to use on the vehicle at this time.
- 2. Open rear hatch and access the trim panel on the passenger side. Remove the trim panel located on the wheel well. locate the programming connector. Two wire will be connected to a plastic connector on the end. Connector will have two terminals.
- 3. Next jump the programming connector using a jumper wire or paperclip. Bend the paper clip or use the two ends of the wire to connect the two ports. Must contact connectors inside the ports. Locks will cycle from lock to unlock signally the entering of programming mode.
- 4. Press unlock on the remote to be programmed locks will cycle again confirming remote has been programmed successfully. Repeat this step for any additional remotes.
- 5. Remove jumper wire or paper clip to exit programming mode.