- 1. Close all the doors including the trunk. Get in the driver's seat and OPEN the driver's door.
- 2. Turn the ignition from ON to OFF (3) times. (ON to OFF = 1 time do it 3)
- 3. OPEN and CLOSE the DRIVER'S side door (3) times.
- 4. The vehicle will respond by cycling the door locks to confirm it has successfully entered programming mode.
- 5. **PUSH** the **LOCK** button **TWICE** on the <u>first remote</u> you are programming (order does not matter). The door locks will cycle to confirm successful programming.
 - **(1 REMOTE)** IF you only have <u>one</u> remote PUSH the LOCK button TWICE <u>TWO MORE TIMES.</u> The locks will cycle to confirm successful programming between each time you press twice. Proceed to step 6.
 - (2 REMOTES) IF you two remotes PUSH the LOCK button TWICE TWO MORE TIMES ON THE SECOND REMOTE YOU ARE PROGRAMMING. The locks will cycle to confirm successful programming between each time you press twice. Proceed to step 6.
 - **(3 REMOTES)** IF you have <u>three</u> remotes PUSH the LOCK button TWICE on the SECOND remote then PUSH the LOCK button TWICE on the THIRD remote. The locks will cycle to confirm successful programming between each time you press twice. Proceed to step 6.
- 6. Programming is complete.