

1. Enter vehicle and close all doors
2. Turn the Alarm Consoles switch to Off.
3. Insert key into the ignition turn to the ON position then back to OFF position ending in OFF 6 times quickly. On position is just before starting the vehicle, OFF is all the way back when key can be removed.
4. Turn Alarm Console to the Auto position then back to OFF.
5. Press Unlock on the remote being programmed. Repeat for additional remotes.
6. Open door and test remotes