- 1. Confirm all doors of the vehicle are closed including the trunk then proceed to step 2.
- 2. Get inside the vehicle and start the programming process immediately.
- 3. INSERT key into the ignition and turn it from OFF to ON (10) times. The vehicle will respond by honking the horn to confirm programming mode.
- 4. OPEN and CLOSE the DRIVER'S side door.
- 5. PUSH the LOCK button the first remote you are programming(Does not matter which). The vehicle will respond by honking the horn to confirm successful programming.
- 6. If you have any additional remotes to program repeat step 5. If you have no additional remotes proceed to step 7.
- 7. REMOVE key. Programming is now complete.