

This procedure is for the FACTORY INSTALLED keyless entry system

1. Start with the key REMOVED from the ignition.
2. Locate the keyless entry module which is located at the front of the center console towards the bottom.
3. Leave the module connected and jump #1 to #9. #1 will have a wire leading towards it while #9 will not. Use a jumper wire to make the connection and leave it connected until instructed to disconnect.
4. The door locks will now cycle to confirm the vehicle has successfully entered programming mode.
5. PRESS the LOCK button the first remote you are programming. (the order in which you program does not matter) The door locks will cycle to confirm successful programming of the remote.
6. If you have any additional remotes to program repeat step 5. If you have no further remotes to program proceed to step 7.
7. Remove the jumper wire from step 3. Programming is now complete.